



HELMITIN
QUALITY ADHESIVE SOLUTIONS

HELMITHERM 430

WHITE HOT MELT FOR HIGH SPEED EDGE BANDERS

Product Description

An economical, high performance, fast setting, EVA edgebanding hot melt adhesive. HELMITHERM 430 is designed to run at high speeds, resist discoloration in the glue pot and give excellent adhesion to a wide variety of common edgebanding materials.

Benefits

- ✓ Lower application temperatures reduce smoke generation and charring
- ✓ Runs clean to minimize machine set-up, cleanup and downtime
- ✓ Fast setting for higher line speeds and increased productivity
- ✓ Excellent adhesion to solid wood edging

Suggested Uses

- Designed for automated edgebanding machinery running at 16 meters/minute or faster.
- Solid and engineered wood edges up to ¼ inch thick.
- PVC, ABS, PP and melamine edgetapes.
- Fleece-backed, paper-backed and raw veneer tapes.
- Primed HPL.

Certifications & Compliance

- Complies with SCAQMD Rule 1168 VOC limits
- California compliant
- OTC compliant

Physical Properties

Base: EVA
Form: Pellets

Application Temperature(s)

- Application roller: 170°C/356°F - 220°C/428°F
- Glue Pot: 170°C/356°F - 200°C/392°F
- Pre-melter: 155°C/311°F - 170°C/338°F

Softening Point: 107 ± 7°C (225 ± 10°F) (ASTM E28)

Melt Viscosity: 155,000 cP @ 200°C/392°F

Specific Gravity: 1.4

Coverage: 1.75 - 4 grams/linear foot (per inch of edge thickness)

Running Speed: 16 m/min +. Open time will vary depending on hot melt, substrate, and ambient temperature, the amount of adhesive applied and compression pressure applied to the edge

Color: White

VHAP: Not applicable.

VOC: 0 lb/gal (0 g/L); less water and exempt solvents

Handling & Storage

- 3 year shelf life from date of manufacture in unopened containers.
- Freeze/Thaw Stable
- Rotate stock to use the oldest material first
- Store at room temperature. 22°C/72°F.
- Keep unused material covered and free from moisture, dirt, dust and/or other sources of contamination

Packaging

- 20 kg/44 lb bags

Clean-Up

- Finished Parts - SOLVENT 665 or HELMITIN CITRUS CLEANER

APPLICATION GUIDELINES

Conditioning of Materials (Cores, Solid Wood, Wood Veneer and HPL Edging)

Allow the core and edge materials to acclimate together at the same temperature and humidity for at least 48 hours before bonding. Optimum conditions are approximately 22°C/72°F and relative humidity of 45% - 55%. Provisions should be made for the circulation of air around the components.

Adhesive Application

1. Regular maintenance of the edgebander in general and glue pot in particular are essential.
 - Remove any buildup of dust and debris at every break.
 - Follow the edgebander manufacturer's preventative maintenance schedule.
2. The first sign of a malfunction in the adhesive application system is often poorly bonded edges.
 - Check the glue pot and application roller temperatures regularly with a good quality IR thermometer or pyrometer to ensure all thermostats and heating elements are functioning properly.
3. Working temperatures are critical when working with hot melt adhesives.
 - For best results, the factory and substrate temperatures should be 20°C/68°F or warmer.
 - Situate edgebanders away from outside doors; cold drafts will adversely affect the bonding ability of the hot melt and lead to edge failures.
4. Solid wood edges require special care when using EVA based hot melts.
 - Edges should be freshly cut or planed; sanding is to be avoided as dust can clog the wood surface and prevent adhesive penetration.
 - If sanding must be done, use 60 grit or coarser.
 - Edge moisture content should be between 6 and 7%; higher moisture content can lead to edge failure if the wood shrinks excessively.
 - Priming the edge with a PVA ("white glue") or contact cement greatly improves adhesion. Allow at least 2 hours for water-based primers to dry completely.
5. HPL edges also require priming when using EVA based hot melts to obtain optimum results.
 - Consider HELMITHERM 470 hot melt to eliminate edge priming and improve adhesion to difficult substrates.
6. **Application temperature depends on the edge material.**
 - 170 - 190°C (340 - 355°F) for PVC and other synthetic edgetapes.
 - 190 - 200°C (355 - 390°F) for veneer tapes.
 - 210 - 220°C (410 - 428°F) for solid and engineered wood, and HPL.
7. Apply enough adhesive to leave a thin, even coat of adhesive which fills all voids in the core material.
 - Excessive adhesive application will cause cleanliness problems on both the finished parts as well as the edgebanders.
8. Adhesive degradation and the build-up of hardened and charred hot melt in the glue pot can be reduced by avoiding the prolonged heating of the hot melt when not running parts through the edgebander.
 - Turn the adhesive temperature(s) down 10 - 30°C when idle and not running parts.
 - If excessive adhesive degradation occurs, remove degraded hot melt from glue pot and add fresh hot melt.
9. Ensure that the compression rollers are applying enough pressure to properly mate the edge to the core.

Warranty

Because Seller has no control over methods of product application or conditions of use, its product is warranted only to be made of standard commercial grade materials and in conformance with Seller's published specifications, if any. Any recommendations for the use of the product are based on tests or experience believed to be reliable and are furnished without compensation, and Seller does not guarantee the applicability or the accuracy of this information or the suitability of its product in any given situation. Buyer must make its own tests to determine the suitability of Seller's product for Buyer's particular use and Buyer assumes all risk and liability of use of Seller's product.

HELMITIN ADHESIVES

Toll Free: 877.823.2624
 inquiries@helmitin.com
 helmitin.com

V1.0



HELMITIN
 QUALITY ADHESIVE SOLUTIONS

*SEE SDS FOR REGULATORY INFORMATION